How to apply Screen Protector Film

- 1) Before applying the film to the device, confirm the film's position and fit on the device.
 - *In order to make application easier, the size of the film has been made slightly smaller than the screen.
 - *In the event that the outer edges of the screen panel are rounded to create a convex surface (Ex.iPhone 6, Galaxy S6 edge), the film should cover only the flat portion of the screen (the entire surface of the panel may not be covered).
 - *Please take care that the film is not upside-down.
- ②Remove the cut-out sections in the film that allow for camera lens, sensors, etc. if its remains.
- ③Use a soft cloth, wipe the whole of LCD screen to remove dirt and dust and clean it.
 - *Using strong force to wipe the LCD screen may cause damage. Please wipe gently and carefully.



④Use adhesive tape to remove any remaining dust or dirt from the LCD screen.


Use the [: Dust Removal Sheet] if included with the product.

*This step is most effective if it is done immediately before attaching the film.



5 Peel off about half of the film from the backing film.

Please avoid touching the adhesive surface to avoid leaving fingerprints.




©Place the film on the edge of the LCD screen that you checked earlier, and apply it slowly, taking care not to let air or dirt get inside.



Once the backing has been completely peeled off and the film has been applied to cover the entire LCD screen, the job is complete.

®Only on the AR and AFP screen protector film, please peel off the protective film on the surface using [★:removal sticker] as a final step.

*Please do not forget to peel this film off.



Please check our website explaining how to apply a screen protector film with pictures.

You can also download pdf files of the manual. http://www.asdec.co.jp/product/how_fi_eng.html ⇒



E-mail: amazon.com@mobilefilm.jp




How to apply the Camera Lens Film

- ①Use a soft cloth and gently clean the camera lens.
- ②Peel off one transparent film for camera lens from the backing film and leave the film half peeled off.


Apply adhesive tape to about half of the film for camera lens, and peel it off the backing film.

Use the [B: Camera Lens Auxiliary sheet] if included with the product.

*Please note: If you put the auxiliary sheet on the film entirely not partially, it may become difficult to apply.



Once you have decided on its position, use one finger to place the film on the camera lens, apply it firmly to the camera lens and then you are ready to go.




What to do in the following cases

If air bubbles are formed:

- OBigger bubbles can be removed by pushing the film outward with your finger.

 Air bubbles
 - *Please rest assured that small air bubbles without any trapped dust or dirt will naturally disappear within one or two days.
- Olf there is trapped dust or dirt, use adhesive tape to peel off the film up to the dirty area, and use the adhesive surface of the tape to take it away.


You can also clean the dirty area of the film with water(if your device is not waterproof, make sure that any water drips are dried off before affixing the film again).





If the film is not affixed in the right place:

- (1) Use adhesive tape to temporarily peel off the film.
- (2) Hold the edge of the film and affix it again onto your device. Take care not to touch the adhesive surface of the film with your fingers.



tape

How to peel off the film:

- (1) Take a long strip of strong adhesive tape and affix it to one of the four corners of the film.

 Adhesive
- (2) Lift off the film gently by pulling on the adhesive tape horizontally, parallel to the film. Once air goes into the edge of the film, it should come off easily.